

Windows7/Vista Driver installation

Please proceed with the following steps to install the driver:

1. Please locate the BvNet Drivers Folder either on the CD-ROM or where you have copied the drivers to if you downloaded them. **Do not plug in your BvNet USB device until the installation has completed.**
2. Run "BvNet Driver Installation.exe". This will run the BvNet driver installation program. Press next.
3. Two drivers will now be pre-installed. A box may appear for each driver about Windows Logo Testing. Please choose Continue Anyway. Driver pre-installation is now complete.
4. You can now plug in your BvNet device. Upon first connection, Windows will locate the drivers and a message should appear on your taskbar informing you that the drivers have been installed successfully. Your BvNet device is now ready to use.
5. An entry will be added to "programs and features" if you wish to uninstall the drivers.

Windows 2000/XP Driver Installation

You need to have administrator privileges to install any new drivers under Windows2000. To install the driver or update the configuration please log onto Windows 2000 as "Administrator" or ask your system administrator to install the USB driver. This is not necessary for XP.

Please proceed as follows to install the driver:

1. Please locate the BvNet Drivers Folder either on the CD-ROM or where you have copied the drivers to if you downloaded them. **Do not plug in your BvNet USB device until the installation has completed.**
2. Run "BvNet Driver Installation.exe". This will run the BvNet driver installation program. Press next.
3. Two drivers will now be pre-installed. A box may appear for each driver about Windows Logo Testing. Please choose Continue Anyway. Driver pre-installation is now complete. You can now plug in your BvNet device.
4. Upon first connection a "Welcome to the Found New Hardware Wizard" window will appear. Please check "No, not this time" and press continue.
5. On the next screen choose "Install software automatically". The driver will now install itself.
6. A box may appear about Windows Logo Testing. Please choose Continue Anyway.
7. Windows has finished installing the software. Click "Finish" to complete the installation.
8. Please repeat steps 4 to 5 for the second driver. Your BvNet device is now ready to use.
9. An entry will be added to "Add/remove programs" if you wish to uninstall the drivers